




SPARE PARTS FOR TIRMASTER T-13



Parts No.	Description	No. per machine
028	Rope guide	1
044	Hex. bolt for casing	11
045	Hex. nut for casing	11
300	Anchor hook(fitted with safety catch)	1
301	Side case R.H.	1
302	Side case L.H.	1
303	Side case boss	2
304	Carrying handle	1
305	Side case bush	2
306	Rear jaw block side plate R.H.	1
307	Rear jaw block side plate L.H.	1
308	Front jaw block side plate R.H.	1
309	Front jaw block side plate L.H.	1
310	Small 1/2 moon jaw link	4
311	Large 1/2 moon jaw link	4
312	Upper jaw	2
313	Lower jaw	2
314	Spacing rivet	8
315	Bottom spindle for 310/311	4
316	Spacing bush for 310/311	4
317	Pin for 319	2
318	Spigot	2
319	Connecting rod(rear jaw)	2
321	Riveted connecting rod(R.H.)	1
322	Riveted connecting rod(L.H.)	1
323	Bottom pin for part 324	1
324	Crank	1

Parts No.	Description	No. per machine
325	Operating handle stud	1
326	Reversing lever	1
327	Center pin for 326	1
328	Upper and lower pin for 326	2
329	Circlip pin for jaw block	1
330	Reversing link R.H.	1
331	Reversing link L.H.	1
332B	Release pressing	1
333B	Release handle	1
334	Spring retaining tube R.H.	1
335	Spring retaining tube L.H.	1
336	Spring rod	2
337	Spring	2
338	Spring anchor plate	1
339	Release spring	1
340	Washer for spring	4
344	Rolet pin	4
345	Circlip	2
347	Countersunk rivet	6
348B	Spring retaining pin	1
350	Share pin	3
351	Plug for carrying handle	1
352	Retainer for shear pin	1
353	Retaining bolt	1
358	Telescopic operating handle	1
359	Rubber grip for 358	1
360	Anchor hook support	1
371	Safety catch	1