




SPARE PARTS FOR TIRMASTER T-7



Parts No.	Description	No. per machine
100	Anchor hook(fitted with safety catch)	1
101	Side case R.H.	1
102	Side case L.H.	1
103	Side case boss	2
104	Rope guide	1
105	Side case bush	2
106	Rear jaw block side plate(R.H.)	1
107	Rear jaw block side plate(L.H.)	1
108	Front jaw block side plate(R.H.)	1
109	Front jaw block side plate(L.H.)	1
110	Small 1/2 moon jaw link	4
111	Large 1/2 moon jaw link	4
112	Upper jaw(front and rear identical)	2
113	Lower jaw(front and rear identical)	2
114	Large spacing rivet(3 per jaw block)	6
115	Bottom spindle	4
116	Crank spacing rivet	1
117	Small spigot for 119(front block)	2
118	Large spigot for 119(rear block)	2
119	Connecting rod	2
121	Top pin for part No. 124	1
122	Grooved pin for part 119	2
123	Bottom pin for part No. 124	1
124	Crank	1
125	Operating handle stud	1

Parts No.	Description	No. per machine
126	Reversing lever	1
127	Centre pin for reversing lever	1
128	Upper and lower pin for reversing lever	2
129	Circlip pin for all	1
130	Reversing link R.H.	1
131	Reversing link L.H.	1
132	Release pressing	1
133	Release handle	1
134	Release spring	1
135	Grooved pin for 133	1
136	Jaw link spacer	4
137	Jaw spring R.H./L.H.	4
138	Spring locating spindle	4
144	Hex bolt for casing(6 x 10)	9
145	Hex nut for casing(6 mm)	9
146	8E circlip	4
150	Grooved shear pin	2
151	Retainer for shear pin	1
152	Retaining bolt	1
158	Telescopic operating handle	1
159	Rubber grip for 158	1
160	Carrying handle	1
161	Plug for carrying handle	1
171	Safety catch	1
(201)	Flat spring	2